


FMM Tronic shower panel WMS, HCP-model
 Head shower outlet

FLOWCHART
 AS A FUNCTION OF INLET PRESSURE




Table

WP [kPa]	Pressure [kPa]	Flow [l/s]	Flow [l/m]
100	98	0,075	4,5
200	197	0,124	7,5
300	296	0,156	9,3
400	395	0,156	9,4
500	499	0,164	9,8
600	598	0,161	9,7

FMM Tronic shower panel WMS, HCP-model
Hand shower outlet

FLOWCHART AS A FUNCTION OF INLET PRESSURE



Table

WP [kPa]	Pressure [kPa]	Flow [l/s]	Flow [l/m]
100	98	0,067	4,0
200	197	0,109	6,5
300	297	0,138	8,3
400	399	0,145	8,7
500	498	0,150	9,0
600	598	0,148	8,9